



Aerogel as a sublimation suppression layer for thermoelectric power generation system

Jong-Ah Paik*, Jeffrey S. Sakamoto, Steven M. Jones, Jean-Pierre Fleurial, and Thierry Caillat

JPL/Caltech




Content





- Introduction
 - Sublimation of thermoelectric materials
 - Aerogel
- Preliminary sublimation rate measurement with aerogel
- Optimization of aerogel
 - Thermal stability of aerogel
 - Shrinkage control (composite aerogel)
- Life time sublimation rate with optimized aerogel and In-gradient test
- Summary and Future work



Brief background : Sublimation phenomenon and beginning of life sublimation rates








Goals:

- Suppress sublimation of antimony vapor to prevent the depletion band from decomposing 5% of the effective cross section after 10 years of operation.
- Contain metal vapor to prevent condensation, which can cause short circuiting on the cold side of the device
- 3) The method of suppression sublimation should not have a significant impact on the system performance




NASA

Sublimation suppression



Overall objectives

- Develop sublimation suppression coating techniques
- Characterize long term efficacy of sublimation suppression coatings





- Background on previous sublimation suppression methods
 - SiGe RTG technology employed Si₃N₄/SiO₂ thin films
 - PbTe/TAGS technology employed an inert cover gas




Brief Background: Aerogel processing









Aerogels:

- Nanometer sized particles surrounded by a continuous microporous and mesoporous volume (porosity >90%, surface area to 1000 m²/g)
- Excellent thermal and acoustic insulator (~ 15 mW/m·K at room temperature in air)



Lawrence Berkeley Lab



Estimated sublimation rate through aerogel




Flux through porous media

$$J = \frac{2}{3} d \frac{\varepsilon}{\tau} \sqrt{\frac{8RT}{\pi M}} \frac{dC}{dx}$$

J=Flux, d=pore diameter of porous media, ε = porosity, τ =totuosity, R=8.314 J/mol·K, T=temperature, M=Molecular weight, C=concentration, x=distance


- If d = 50 nm, density of aerogel = 200 mg/cc, and x = 5 mm, estimated sublimation rate of Sb through aerogel at 700C is ~5.85×10⁻⁷ g/cm²hr.
- Aerogel is expected to show better sublimation suppression property with increasing density.
 - Average pore diameter decreases with increasing density






Thermal stability of aerogel








- Aerogel shows little shrinkage (~ 1%) with 700 C under vacuum.
- Most of shrinkage happens at early stage of heating, which explains longterm stability of aerogel.
- There was no detectable degradation of aerogel during coupon life test up to 6 months.



Preliminary sublimation rate measurement with TGA




Measuring Sublimation Suppression of Aerogel Coatings using the TGA





Coupons tested at 700C in high vacuum (TGA)






□@ 700C

- \square Uncoated: 2 x 10⁻² g/cm²h
- \square 50mg/cc aerogel: 3 x 10⁻³ g/cm²h
- \square 100mg/cc aerogel: 1 x 10⁻³ g/cm²h
- Demonstrated that aerogel does slow sublimation, but not as much as expected.



Initial sol gel process results in ~10% isotropic shrinkage




Cracks likely caused higher than expected sublimation rates




Shrinkage control of aerogel (composite aerogels)







Clear aerogel



Composite aerogel

Acceptable shrinkage level

Shrinkage reduction

- Adding additional precursor during synthesis
- Adding solid particles to strengthen aerogel
- Changing precursor from TEOS (tetraethoxysilane) to TMOS (tetramethoxysilane)

Higher density is desirable for sublimation suppression


- Shrinkage control is required to cast crack free higher density aerogel
- Incorporating powder is another mean to increase the density of aerogel without increasing shrinkage



Crack free aerogel encapsulation








Demonstration of casting aerogel around dummy graphite legs

50 mg/cc




120 mg/cc



Coupons for TGA sublimation test (encapsulating a graphite cup containing an antimony puck)






Encapsulation of TE modules



Crack free aerogel encapsulation (SEM pictures)



Current best aerogel: ~ 150 mg/cc (75 mg/cc aerogel, 20 mg/cc fumed silica, 50 mg/cc granular silica)




• SEM pictures show intimate contact between aerogel and skutterudite after 7 days at 700C under vacuum (Aerogel filled 500 μ m gaps (depth ~ 5 mm) generated on skutterudite disc with checker board arrangement).



Sublimation suppression with aerogels








| | | Un-encapsulated (g/cm2hr) (vacuum) | Cast aerogel (g/cm²hr) (vacuum) |
|------------------------|--------|---------------------------------------|------------------------------------|
| n-type skutterudite | 400 °C | Not detected | Not detected |
| | 500 °C | 5.31 × 10 ⁻⁴ | Not detected |
| | 600 °C | 5.16 × 10 ⁻³ | Not detected |
| | 700 °C | 2.15 × 10 ⁻² | 1.15 × 10 ⁻⁴ |

- No detectable sublimation rate at 600 °C (< 1×10⁻⁵ g/cm²hr)
- Aerogel reduced sublimation rate significantly at 700 °C and life test was set up for accurate sublimation rate measurement



Sublimation life test (700C)






Aerogel reduces sublimation rate at 700 °C as much as 1000 times



Sublimation life test (600C)






Demonstrated that desired sublimation rates ($\sim 5 \times 10^{-7}$ g/cm²hr) for 14 years of operation can be achieved up to 875K for aerogel-encapsulated low-T skutterudites after up to 4000 hours of testing




In-gradient test





- Sb penetration into aerogel was significantly suppressed during ingradient test due to temperature gradient across aerogel.
- Sublimation could be much slower during in-gradient test which is close simulation of real situation.

SKD








In gradient test (Skutterudite module after 7 days at 700C (10⁻⁶ torr))





- Potential advantage of aerogel for thermoelectric power system
 - serving as a sublimation barrier and thermal insulation simultaneously
 - easy processing by casting around structure
 - Tailoring for better thermal conductivity (adding opacifying agent)



Summary



- Aerogel process was optimized to reduce shrinkage and crack free encapsulation was demonstrated with several structures
- Aerogel reduced sublimation rate by factor of 1000 at 700 °C and ~5 x 10⁻⁷ g/cm²hr sublimation rate was achieved with aerogel coupons at 600 °C.
- Coupons were tested more than 6 months and aerogel shows no apparent degradation.
- Excellent thermal insulation properties of aerogel can improve sublimation suppression in real situation (in-gradient test).
- Additional sublimation layers are under development in order to reduce sublimation rate further at 700 °C.