

# Camera, Hand lens, And Microscope Probe (CHAMP):

**An Instrument  
Proposed for the  
2009 MSL Rover  
Mission.**

Greg S. Mungas<sup>1</sup>, Luther W. Beegle<sup>1</sup>,  
John E. Boynton<sup>1</sup>,  
Pascal Lee<sup>2</sup>, Ritch Shidemantle<sup>3</sup>,  
Ted Fisher<sup>4</sup>  
and the CHAMP investigation team\*

1 Jet Propulsion Laboratory, 4800 Oak Grove Dr., Pasadena, Ca 91109

2 SETI Institute, 515 N. Whisman Rd, Mountain View Ca, 94043


3 Lockheed Martin

4 Firestar Engineering, LLC, 557 Burbank St. Unit J, Broomfield Co, 80020




**The MIDP heritage CHAMP imager (Left) as shown deployed on the NASA ARC K9 Rover as it approaches a field sample (center) and in the preloaded into a target rock for stable microscopic imaging. (Figure courtesy of Maria Bualat and MSL CHAMP team member Matt Deans)**

**LED manifold**  
2 White + 1UV per  
quadrant. (Coupler to  
fiber optic not shown)




**Lens Cell 1**




**Dust protection  
Seal**




**8 position  
Filterwheel  
assembly**



Schematic of the proposed



**MSL microscopic imager**






The redesigned snub nose illumination system is especially designed to achieved controlled lighting when CHAMP is utilizing the highest spatial resolution. The bottom graph shows the time to 50% Full well Using parameters from the Pancam filters and target reflectances with 4 White LED, under full quadrant illumination

CHAMP will allow examination of martian surface features and materials (terrain, rocks, soils, samples) on spatial scales ranging from kilometers to micrometers, thus enabling both microscopy and context imaging with high operational flexibility. CHAMP is designed to allow the detailed and quantitative investigation of a wide range of geologic features and processes on Mars, leading to a better quantitative understanding of the evolution of the martian surface environment through time.


In particular, CHAMP will provide key data that will help understand the local region explored by MSL as a potential habitat for life. CHAMP will also support other anticipated MSL investigations, in particular by helping identify and select the highest priority targets for sample collection and analysis by the MSL's analytical suite.

We have proposed a single contact imaging experiment for NASA's 2009 Mars Surface Laboratory (MSL) rover mission with three core science objectives:


- 1) Assess the MSL landing region's biological potential by searching for morphologic/textural biosignatures in rocks and soil
- 2) Characterize potential habitats on Mars, focusing on past aqueous environments and past (or present) endolithic habitats
- 3) Characterize the local geology and geologic evolution of Mars, in particular in relation to H<sub>2</sub>O.



**Examples of Z-Stacking and range determination. Raw Images of Hematite at Different Focus Positions (A-D) “Z-Stacked” into a Single Composite In-Focus Image (E). (F) depicts CHAMP’s change in IFOV vs. Working Distance Including Z-stack Range Estimates. (G) Illustrates CHAMP’s Precision Rangefinding Capability.**



A very simple and sensitive metric that has been initially proposed for MSL CHAMP is to use the compressed file size of the z-stack images given the larger file sizes required for storing in-focus images with higher spatial frequency components. Example of Best Focus Calculated from Compressed Image File Size.



	<i>Microscopy</i> ← ——— Object Distance [mm] ———→ <i>Infinity</i>								
	7	8	9	10	13	27	43	153	Infinity
<b>Pixel Resolution - Instantaneous Field of View (IFOV) [<math>\mu\text{m}/\text{pixel}</math>]</b>	2.9	3.1	3.5	4.3	5.8	12	21	75	0.48 millirad
<b>Field of View (FOV) [mm]</b>	1.9	2.0	2.2	2.8	3.7	8.1	13	49	-----
<b>Depth of field [<math>\mu\text{m}</math>]</b>	45	48	52	62	84	220	476	4600	-----
<b>Illumination</b>	UV or White LED				White LED		Passive Lighting		
<b>Spectral Range/Filters</b>	460-650nm / 7 Filters (RGB) + 1 Dark Current Calibration								

In the process of producing a in-focus Z-Stacked image, topographic information can be obtained by using the best focus and range determination from a stack of 40 images.


	<b>Microscopy</b> ←———— <b>Object Distance [mm]</b> —————→ <b>Infinity</b>									
	<b>7</b>	<b>8</b>	<b>9</b>	<b>10</b>	<b>13</b>	<b>27</b>	<b>43</b>	<b>153</b>	<b>Infinity</b>	
<b>Pixel Resolution - Instantaneous Field of Fiew (IFOV) [<math>\mu\text{m}/\text{pixel}</math>]</b>	2.9	3.1	3.5	4.3	5.8	12	21	75	0.48 millirad	
<b>Field of View (FOV) [mm]</b>	1.9	2.0	2.2	2.8	3.7	8.1	13	49	-----	
<b>Depth of field [<math>\mu\text{m}</math>]</b>	45	48	52	62	84	220	476	4600	----	
<b>Illumination</b>	UV or White LED				White LED		Passive Lighting			
<b>Spectral Range/Filters</b>	460-650nm / 7 Filters (RGB) + 1 Dark Current Calibration									

	<b>CHAMP [1]</b>	<b>MER micro-imager [2]</b>	<b>Phoenix RAC [3],[4]</b>	<b>Beagle 2 Microscope [5]</b>	<b>MECA Microscope [3]</b>
<b>Microscopic Imaging Resolution (IFOV) w/ Working Distance</b>	<b>3 micron/pixel at 6mm</b>	30 micron/pixel at 66mm	23 micron/pixel at 11mm	4-6 micron/pixel at ??	4 micron/pixel at ??
<b>Field of View at Focus Position</b>	Infinity imaging (10°) continuous down to FOV=1.50 mm	30mm	Infinity Imaging to FOV~23mm	4mm	~1.5mm
<b>Rover Approach and Arm Pointing</b>	Supports arm pointing to features continuously magnified	Supports Arm Pointing	Supports Arm Pointing	NA	NA
<b>Illumination</b>	White and UV LED's for microscopy, passive lighting for approach	Passive Lighting	3 Color LEDs	3 Red, 3 Green, 3 Blue, 3 UV	3 color +1UV LED
<b>Spectral Bands</b>	Filter wheel 8 band selectable (460-650nm)	400-680nm	400-700nm wideband	Dependent on illumination	Dependent on illumination
<b>Rough Surface Accommodation</b>	Z-stacking with 10 micron step resolution	Z-stacking with arm to ~mm's resolution	Z-stacking with ~10 micron step resolution	Z-stacking with 10 micron step resolution	?


- 1 Boynton et. al. 2002, "Camera Handlens Microscope (CHAMP)", MIDP Final Report, JPL Contract #961-495**
- 2 Herkenhoff, K.E., et. al. 2003, JGR Vol. 108, E12, 8063, doi: 10.1029/2003JE002076**
- 3 Smith, P., H. U. Keller, 2001, "The Robotic Arm Camera for Mars Surveyor 2001", Workshop on Mars 2001**
- 4 Reynolds, R.O., et. al. 1997, SPIE Vol. 3132, pp. 78-85**
- 5 Thomas, N. et. al. 2003, "The Microscope for the Beagle 2 Lander...", 6th Internatl. Conf. Mars**

Examples of images obtained  
with the MIDP heritage CHAMP

# Able to image in color (R, G, B) over several spatial scales




IFOV = 0.48mrad/pixl



Magnification = 0.28  
Horizontal FOV ~ 16.8 mm




Magnification = 0.70  
Horizontal FOV ~ 6.5 mm



Magnification = 4.5  
Horizontal FOV ~ 1.0 mm

# Continuously variable focus capabilities.




$\infty \Rightarrow 0.48 \text{ mrad/pixel}$




IFOV=60  $\mu\text{m}/\text{pixel}$



IFOV=30  $\mu\text{m}/\text{pixel}$





IFOV=9  $\mu\text{m}/\text{pixel}$




IFOV=3  $\mu\text{m}/\text{pixel}$




# Maximum spatial resolution of 3 microns/pixel




# Controlled lighting (white and UV)





Series of images of loose, unconsolidated soil material. By imaging over several spatial ranges diversity of this material can be explored as well as particle counting so that size distributions can be determined.







IFOV=19; FOV=12.4mm

IFOV=12; FOV=8.2mm

IFOV=6; FOV=3.8mm

IFOV=3; FOV=1.9 mm

By utilizing the continual zoom when imaging a field sample we can image features that are not evident at the scale that the MER MI operates.



Color images of a hematite fossil at several  
spatial scale obtained with the CHAMP MNIDP  
instrument

# Acknowledgments

This work described here was carried out at Jet Propulsion Laboratory, California Institute of Technology, and was sponsored by the National Aeronautics and Space Administration's ASTID program.

We gratefully acknowledge Maria Bualat, Dan Klein, Tim Crist, Gabe Hamilton, Jack Loui, Michael Buck, Abhi Tripathi, Josiah Jordan and Sean Sherrard for their tireless work in the development of the MIDP instrument.

Finally, we wish to thank George Lawrence who was the PI of the MIPD development at LASP for invaluable contributions to the design of CHAMP.