



Jet Propulsion Laboratory



Sodium Borohydride/Hydrogen Peroxide Fuel Cells For Space Application

T. I. Valdez, M. E. Deelo and S. R. Narayanan

Jet Propulsion Laboratory, California Institute of Technology

209th Electrochemical Society Meeting
Los Angeles, California

Electrochemical Technologies Group




Presentation Outline

- Motivation
- The Sodium Borohydride Fuel Cell
- Sodium Borohydride Fuel Cell Test Stand
- Fuel Cell Comparisons
- MEA Performance
- Anode Polarization
- Electrode Analysis
- Conclusions



Hydrogen Peroxide Fuel Cell Systems




- Hydrogen peroxide can be used as an alternative oxidant for PEM based fuel cells in any application which can see a limited amount of free convection air.
- The sodium borohydride/hydrogen peroxide fuel cell offers distinct advantages:
 - Theoretical energy density: 2500 Whr/kg
 - Simplified thermal handling, liquid reactants





The Sodium Borohydride/Hydrogen Peroxide Fuel Cell




- Benefits of hydrogen peroxide as an oxidant
 - Higher current density from larger oxidizer mass density
 - Single-phase transport on the cathode side of FC increases reaction rate
- Benefits of sodium borohydride as a fuel
 - Sodium and Borate do not react electrochemically: neither pass through the PEM and both stay at anode side
 - NaBH₄ is 30-40% soluble in water: can be used as a liquid directly at the anode, promising higher current density and efficiency
- Waste heat removed by oxidizer and fuel both in liquid form, giving better cooling






NaBH₄/H₂O₂ Fuel Cell Test Stand



- MEA Fabrication Technique
 - Fabricated via a JPL direct deposit technique
 - Catalyst is deposited onto the PEM
 - Electrodes are hot pressed on the catalyzed PEM
- MEAs Fabricated
 - Pd-Pt (Anode-Cathode)
 - Pt-Pt
 - Au-Pt
- Reactant Specifications
 - Fuel: 5 to 10% NaBH₄ (Alfa-Aesar)
 - Oxidant: 5 to 10% H₂O₂ stabilized -CMOS grade solution (J. T. Baker)
 - All solutions were diluted in a 10 NaOH solution made with 18.2 mΩ water. (J. T. Baker)
 - Operating the cell with sodium hydroxide in both the anode and cathode compartments eliminates the sodium gradient across the Nafion membrane




Methanol-Based Fuel Cell Performance Comparison



- Comparison of liquid-feed direct oxidation fuel cells at room temperature and ambient pressure operation.
- The maximum power density measured for the sodium borohydride/hydrogen peroxide system, at 30 °C, is 48 mW/cm². These values are higher (>2x) than that of a methanol/hydrogen peroxide system operated under similar conditions.




Current-Voltage Characterization as a Function Oxidant Concentrations, Cell Operating at 30 °C, Pd Anode



- Cell peak power density increases by 22% as the hydrogen peroxide concentration increased from 5 to 10%




Current-Voltage Characterization as a Function Oxidant Concentrations, Cell Operating at 40 °C, Pt Anode



- Cell peak power density of 140 mW/cm² possible at high hydrogen peroxide concentrations




Current-Voltage Characterization as a Function Oxidant Concentrations, Cell Operating at 40 °C, Au Anode




- Gold anode produces lower power




Anode Polarization Technique



Electrochemical Reaction



Anode Polarization, 5% Sodium Borohydride, 30°C





Test Set-up

- A solution of sodium hydroxide, of the same concentration used to dilute the fuel, is introduced into the cathode compartment of the fuel cell. This eliminates the sodium gradient across the Nafion membrane.
- When current is pulled from the cell, the sodium borohydride is oxidized at the anode and the product hydrogen formed at the cathode allows this electrode to function as a dynamic hydrogen electrode.
- The sodium hydroxide solution is used to sweep product hydrogen away from the cathode and maintain the pH of this electrode at the same level of the anode.
- When the cell is polarized, the resultant curve will be E_a vs. current density of the cell.

Electrochemical Technologies Group




The Effect of Fuel Concentration on Anode Polarization Performance



- The polarization plots, as a function of concentration, slightly diverge at current densities above 300 mA/cm²
- Fuel flow rate has a minimal effect on anode performance





Anode Polarization Performance as a Function of Temperature



- Tafel slopes for each of the anode polarization plots are in the range of a 100's of mV/decade


- A process beyond charge transfer might be present during the electrochemical oxidation of the sodium borohydride fuel on the palladium catalyst/carbon paper



Electrochemical Technologies Group




Activation Energy for the Platinum/Carbon Paper Electrode



- Activation energy for the reaction on the platinum catalyst/carbon paper structure is calculated to be 21 kJ/(mol oK)




Anode Polarization Analysis, Cells Operating at 40 °C



- An ideal catalyst for the oxidation of sodium borohydride would operate at a potential below -0.83 V vs. NHE and preferably as low as -1.64 V vs. NHE



Polarization Analysis for a Cell Operating at 40 °C




- E_{cell} , at any oxidant concentration and flow rate, can be added to E_{a} at the same fuel molarity and temperature to get E_{c} corresponding to oxidant concentration and flow rate.

$$E_{\text{c}} = E_{\text{cell}} + E_{\text{a}}$$

- When E_{a} and E_{c} are plotted together as a function of current density, the kinetics of the reaction can be seen.



Cathode Polarization Analysis, Cell Operating at 40 °C



- For cell operation on 5% hydrogen peroxide, the cathode will become mass transfer limited for current densities greater than 240 mA/cm²



Conclusions

- The maximum power density measured for the sodium borohydride/hydrogen peroxide system, at 30 °C, was 58 mW/cm². These values are higher (>2x) than that of a methanol/hydrogen peroxide system operated under similar conditions.
- MEA data taken with the Anode Polarization Technique was useful in separating the anode and cathode performance
- Electrode polarization analysis revealed that both the anode and cathode of the cells were underperforming electrochemically.
- The cathode performance was just above 0 V vs. NHE which is well below that expected values for oxygen and hydrogen peroxide in alkali environments.
- To improve the present system, catalyst that are more selective towards the oxidation of sodium borohydride and more selective towards the reduction of peroxide are required. In light of previous work on the methanol/hydrogen peroxide system, a cathode catalyst has the secondary requirements of being tolerant to NaBH₄/NaBO₂/NaOH.



Acknowledgements



The work presented here was carried out at the Jet Propulsion Laboratory, California Institute of Technology for the National Aeronautics and Space Administration. Studies on sodium borohydride/hydrogen peroxide fuel cells were performed under a program led by Professor George Miley of the University of Illinois, Urbana-Champaign

